

URGENT SAFETY NOTICE

DO NOT OPERATE GAS RANGE COOKERS WITH THE GRILL DOOR CLOSED.

When the grill is operating the grill door must always be in the open position. If the grill is operated with the grill door closed, the air supply to the grill burner is restricted causing dangerous levels of carbon monoxide to be produced.

110cm

444440792 ST STERLING R1000GT Blk
444440793 ST STERLING R1000GT Sta
444440798 ST STERLING R1100GT Blk
444440799 ST STERLING R1100GT Sta

100cm

444440792 ST STERLING R1000GT Blk
444440793 ST STERLING R1000GT Sta
444440798 ST STERLING R1100GT Blk
444440799 ST STERLING R1100GT Sta

90cm

444410272 ST RICH DX S900G CB Wbe
444410273 ST RICH DX S900G CB Hja
444410274 ST RICH DX S900G CB lbr
444410275 ST RICH DX S900G CB Dab
444410276 ST RICH DX S900G CB Mga
444410277 ST RICH DX S900G CB SH Grn
444410278 ST RICH DX S900G CB Ant
444410761 ST PREC DX S900G BK
444410762 ST PREC DX S900G SS
444410797 ST RICH S900G BK
444410798 ST RICH S900G CC
444410799 ST RICH S900G Ant
444410806 ST STER S900G BK
444410807 ST STER S900G SS
444410923 ST RICH DX S900G CB Agr
444410924 ST RICH DX S900G CB lwh
444410925 ST RICH DX S900G CB Pmu
444410926 ST RICH DX S900G CB Cbl
444410927 ST RICH DX S900G CB Mmi
444410928 ST RICH DX S900G CB Cre
444410929 ST RICH DX S900G CB Mbl
444410930 ST RICH DX S900G CB Tbl
444410931 ST RICH DX S900G CB Kte
444411272 ST RICH DX S900G CB Bgr
444443481 ST RICH 900GT Blk
444443482 ST RICH 900GT Cha
444444903 ST RICH DX S900G BK

444444904 ST RICH DX S900G CC
444444935 ST STER DX S900G BK
444444936 ST STER DX S900G SS

Safety:

If you own any of the aforementioned gas range cookers, **YOU MUST ONLY USE THE GRILL WITH THE DOOR OPEN, as detailed in the instruction manual.**

If you have any concerns, please call 0800 110 5728 with your product code and serial number. The lines are open 9-5pm Monday – Friday. The serial number can be found on the data plate at the front edge of main oven door and on the rear of the appliance.

Appliance Use:

All gas appliances must be installed and operated in accordance with the manufacturer's instructions supplied with the cooker. Correct use and adequate ventilation is essential to ensure safe use of these cookers. Using an appliance for any purpose, other than that for which it is designed, can cause serious safety issues. The grill cavity in these appliances is designed for open door grilling and the grill must not be used as an oven, a space heater, or any other purpose.